

MaxKeyboard

Max Keyboard Nighthawk series macro assignment and software installation guide

SOFTWARE INSTALLATION

Step 1: Please plug-in the Nighthawk mechanical keyboard on any available USB port on your computer.

Step 2: Double click on the "**SETUP.EXE**" to install the software.

Step 3: The setup instruction will guide you through the setup process.

Step 5: After installation, click the finish button to restart your computer and to finish the installation process.


Please refer to the following illustration below to better help you.




A) Select your desire language




B) Click NEXT to continue with the setup wizard




C) Click NEXT to continue to install the software on the default folder



D) Click NEXT to create the program shortcut in the following folder



E) Click INSTALL to proceed with the software installation



F) Click INSTALL to install OEM HID device driver for the keyboard



G) Please click FINISH to restart your computer

UNINSTALL SOFTWARE

Step 1: Open control panel

Step 2: Select Add/Remove Programs icon

Step 3: Select "**GAMING KEYBOARD**" from the installed program lists

Step 4: Click "**REMOVE**" button, then the system will remove the software

SOFTWARE OVERVIEW



1	Profile Tab Selection	6	Macro key toggle button
2	Import your configuration file	7	Macro key setting
3	Save setting to current profile	8	Launch Help file
4	Save and close the current profile and software window	9	Minimize software window
5	Reset current profile to default keyboard function	10	Close software

MACRO KEY BASIC SETUP GUIDE

Here we will do a quick macro setup example

A) Click on **PROFILE 1**

B) Click on **M1** (it will started to flash)

C) Now **select** and **click** on the key you want to program (Here we are going to select "1")

D) Go back to **M1**, click on the drop down box then select "**MACRO**" A macro screen window will pop up

E) On the macro window click "**RECORD**", now you can record/type your key sequence.

F) Click "**STOP**" to end key recording, then Click "**OK**" to save Macro

(Please refer to illustration below)



